




## RAIL KIT, MERCEDES METRIS LWB



**PRODUCT WEIGHT**  
20 LBS

**WIDTH x DEPTH x HEIGHT**  
NA" x NA" x NA"

**CAPACITY**  
N/A

**COLOR**  
RAW ALUM / GRAY

**CATALOG NUMBER**  
RKMMLWB

### **PRODUCT FEATURES**

**This product is designed for installation in a Mercedes Metris long wheel base, standard roof. RAIL KIT MUST BE INSTALLED WITH THE ASCO PARTITION.**

**SEE PAGE 2 FOR APPLICATION NOTES AND ACCESSORIES, OTHER PRODUCTS THAT WORK WITH THIS UNIT.**

### **PAGE 1 of 2**

The information contained in this document is the sole property of ADRIAN STEEL COMPANY. ADRIAN STEEL COMPANY retains the right to modify and/or change the product of its design at any time without prior notification.



## RAIL KIT, MERCEDES METRIS LWB

**CATALOG NUMBER**      **RKMMLWB**

### ***PRODUCT APPLICATION***

**This product is designed for installation in a Mercedes Metris long wheel base, standard roof. RAIL KIT MUST BE INSTALLED WITH THE ASCO PARTITION.**

### ***ACCESSORIES THAT WILL WORK WITH THIS PRODUCT***

<b><i>CATALOG NUMBER</i></b>	<b><i>DESCRIPTION</i></b>
<b>AD44XX</b>	<b>AD44 SERIES SHELF MODULE</b>
<b>AD32XX</b>	<b>AD32 SERIES SHELF MODULE</b>
<b>AD50XX</b>	<b>AD50 SERIES SHELF MODULE</b>

**SHELVING UNITS MUST HAVE THE 46" TALL END PANEL**

### ***SPECIAL APPLICATION NOTES***


**Introduction / Comments:**

THIS RAIL KIT IS INTENDED TO BE USED IN THE MERCEDES-BENZ METRIS LWB

**Note:**

It is advised that all fasteners used in this assembly and installation should be checked for tightness at the following intervals: @ 2-weeks and again @ 6-weeks of operation. This preventive maintenance step must be completed to ensure your Product gives you long service life.

ITEM NO.	PART NUMBER	DESCRIPTION	RKMMLWB/QTY.
1	57137	RAIL 97", METRIS LWB	1
2	57143	RAIL 100.94", METRIS LWB	1
3	57144	RAIL, 56" METRIS LWB	1
4	57145	RAIL 59.50", METRIS LWB	1
5	HDW57485 CLOSED	HDW,KIT,RKMMLWB	1



**RKMMLWB  
RAIL KIT, MERCEDES METRIS, SINGLE SLIDING DOOR**

## - PRECAUTIONS -



**CAUTION**  
THE USE OF AIR IMPACT TOOLS CAN  
OVER-TORQUE FASTENERS AND  
CAUSE FASTENER FAILURE!



**CAUTION**  
ALL INSTALLATION HOLES SHOULD BE SEALED  
WITH SILICON OR BUTYL SEALANT TO PREVENT  
EXHAUST FUMES FROM ENTERING THE VEHICLE!



**DANGER**  
INSPECT FOR FUEL TANK, FUEL LINES, BRAKE LINES, HIGH  
VOLTAGE BATTERIES AND ELECTRICAL LINES PRIOR TO  
DRILLING TO AVOID DAMAGING CRITICAL VEHICLE SYSTEMS  
OR INJURY TO INSTALLER DURING INSTALLATION PROCESS!



**CAUTION**  
TO AVOID DAMAGING THE VEHICLE ALWAYS USE DRILL  
STOPS WHEN DRILLING ANY INSTALLATION HOLES!  
ADRIAN AVAILABLE PART #'S 31119-0 (3/8" X 1/2"  
DEEP), 31121-0 (1/2" x 1/2" DEEP)



## - IMPORTANT WARRANTY REQUIREMENTS -

1. SUBSTITUTING ADRIAN STEEL SPECIFIED FASTENERS FOR ASSEMBLY AND/OR INSTALLATION WILL VOID YOUR PRODUCT WARRANTY.
2. ALL HOLES DRILLED INTO VEHICLE SHOULD HAVE THE RAW METAL EDGES SEALED WITH A SELF-ETCHING PRIMER TO RESIST CORROSION AND POTENTIAL FASTENER POINT FAILURE.
3. ALL FASTENERS USED IN THE INSTALLATION OF THIS PRODUCT SHOULD BE TIGHTENED TO THE TORQUE(S) SPECIFIED IN THESE INSTRUCTIONS.
4. THESE INSTRUCTIONS SHOULD BE KEPT WITH THE VEHICLE.

### THE BASIC TOOLS NEEDED FOR MOST INSTALLATIONS



DRILL



DRILL BIT WITH  
STOP



RATCHET, SOCKETS  
AND/OR WRENCHES




SCREWDRIVERS



MEASURING TAPE

ADDITIONAL TOOLS MAY BE NEEDED FOR THIS INSTALLATION AND THEY WILL BE IDENTIFIED IN THE STEPS THAT FOLLOW.

If your vehicle contains carpet or a rubber floor mat you will need to prepare the mounting location. Position the product to be installed into the vehicle and once you are satisfied with the mounting locations, mark the mounting locations. Using a 1-3/16" diameter carpet cutter (P/N: 31183-0). Select the appropriate floor spacers as shown in the illustration. Set those aside for use later into the installation process. Using the correct drill bit size for the selected plusnut, drill the mounting holes in the vehicle sheet metal to prepare for installing the plusnuts. If you are thru-bolting at any of the locations simply drill a hole that is 1/16" larger than the bolt size(s) for those locations. Once you have drilled the holes into the vehicle, the raw metal edges should be sealed using a self-etching primer to resist corrosion and potential fastener point failure.



A PLUSNUT (RIVNUT) SETTING TOOL IS REQUIRED FOR PLUSNUT (RIVNUT) INSTALLATION . PLUS NUT SETTING TOOL CAN BE ORDERED THROUGH ADRIAN STEEL, OR USE AN AIR POWERED PLUSNUT SETTING GUN.


1/4-20UNC Plusnut (FAS0052) Use 3/8" dia. drill w/stop  
 FAS0080 SCREW, HXHD, 1/4-20UNCx2.00", G8  
 FAS0067 WASHER, FLAT, 1/4"ID  
 22200-0 PLUSNUT TOOL

5/16-18UNC Plusnut (FAS0091) Use 1/2" dia. drill w/stop  
 FAS0095 SCREW, HXHD, 5/16-18UNCx2.00", G8  
 FAS0086 WASHER, FLAT, 5/16"ID  
 22200-0 PLUSNUT TOOL


Place barrel of the plusnut body in sheet metal thru hole until flange is flush with sheet metal. Using a 9/16" combination wrench of plusnut tool body and a second hand wrench, ratchet, or air tool, rotate the hex bolt head CW to draw plus nut flanges up (set the plusnut).

**Installation and/or Assembly Fasteners  
BAGRKMM—BAG, RKMM, METRIS**

ITEM NO.	PART NUMBER	DESCRIPTION	BAGRKMM/QTY.
1	FAS0708	Screw, Button Hd Hex Soc, 5/16-18X1.25, BLK OXIDE	4
2	FAS0091	Plusnut, 5/16	14
3	FAS0165	Screw, Hex Hd, 5/16-18x.625	12
4	FAS0085	Washer, Lock, Ext. Tooth, 5/16	24
5	FAS0086	WASHER,FLAT USS 5/16 ZP	14
6	BAG0510-A	5'X9" 4MIL AUTOBAG	1
7	03927-2	Tall Floor Spacer	8
8	FAS0098	Washer, Lock, Split, 5/16, Zinc Plate	2
9	FAS0081	Screw, Hex Hd, 5/16-18x0.75 Zn Plate	2
10	FAS0018	SCREW,HH SFLNG 1/4-20X.62 ZP	1
11	FAS0055	Nut, Hex Flange,Nylock 1/4-20	1
12	FAS0048	Screw, Button Hd Hex Soc, 5/16-18X 2, BLK OXIDE	8



**Step 01** PLACE FLOOR RAILS INTO THE VAN AS SHOWN





FLUSH WITH WHEEL WELL. EACH SIDE




**Step 02 FASTEN RAILS TO FLOOR USING FASTENERS SHOWN FOR VEHICLE WITH WOOD FLOOR. DO NOT USE SPACERS IF NO WOOD FLOOR.**




**REFER TO PAGE 3 FOR INSTALLING PLUSNUTS**




**Step 03** INSTALL BRACKET ONTO RAIL AS SHOWN




**Step 04** PLACE UPPER RAILS 39 1/2" INCHES OFF THE FLOOR TO THE BOTTOM OF THE RAIL  
MARK THE 4 MOUNTING POINTS ON STREETSIDE AND 2 ON CURBSIDE. DRILL AND SET PLUSNUTS



**Step 05** ATTACH THE RAILS TO WALL OF VAN USING THE LOCATIONS IN THE PREVIOUS STEP. PRIOR TO INSTALLING RAILS, INSERT 2 SLIDES PER SHELF TO THE UPPER RAILS.




**Step 06** PLACE THE SHELVING UNITS INTO THE VAN AND ATTACH TO RAILS AS SHOWN. INSTALL 2 SLIDES (35335-0) INTO EACH RAIL PER SHELF INSTALLED




**WALL MOUNTING**

**FLOOR MOUNTING**

**ING**



INSERT AN END CAP (36496-0) INTO THE REAR OF THE RAILS, AND THE FRONT OF BOTH CS RAILS. 4 TOTAL.



**DOUBLE CHECK ALL FASTENERS LOCATIONS TO BE SURE THAT ALL FASTENERS ARE TIGHTENED TO SPECIFICATIONS.  
YOUR INSTALLATION IS NOW COMPLETE!  
STOW THIS COPY IN THE VEHICLE FOR FUTURE REFERENCES!**