



## 2-Crossbar Kit, 84", White, Trailer



PRODUCT WEIGHT  
**23.4 LBS**

CROSSBOW LENGTH X  
HEIGHT

**85" x 2"**

CAPACITY

**REFER TO OEM'S  
RECOMMENDED LOAD  
RATING**

COLOR

**WHITE**

CATALOG NUMBER

**2BARTRW**

### PRODUCT FEATURES

Aluminum base 2-crossbow kit for PROFILE™ HD Utility, PRO-LIFT, or combo ladder racks.  
Works with MOST trailers (rounded top and box top).

Additional crossbows and optional uprights and conduit kits are available!

HD Utility ladder racks are not recommended for high roof vehicles!

Please refer to OEM specific mounting kit or rail kit for additional information on compatible accessories.

# INSTALLATION GUIDE FOR PROFILE™ SERIES LADDER RACKS

INSTRUCTION #:  
**68895**

REV:  
**C**



THIS INSTRUCTION PROVIDES A GENERAL GUIDE OF INSTALLATION SEQUENCE FOR ALL PROFILE™ SERIES LADDER RACKS. PLEASE ENSURE ALL ACCESSORIES ARE INSTALLED PER TYPE OF RACK BEFORE PROCEEDING TO NEXT PAGE.

REFERENCE THIS INSTRUCTION THROUGHOUT THE ENTIRETY OF YOUR INSTALL TO PREVENT ACCESSORIES BEING INSTALLED INCORRECTLY/OUT OF SEQUENCE!

**STEPS 2T - 8T ON PAGE 3 IS THE RECOMMENDED ASSEMBLY SEQUENCE FOR A FULL TABLE ASSEMBLY BEFORE INSTALLING ON THE ROOF OF THE VEHICLE.**


**STEPS 2R - 8R ON PAGE 4 IS AN ALTERNATE ASSEMBLY SEQUENCE TO INSTALL THE RACK ON THE VEHICLE ROOF AS IT IS BUILT.**

PLEASE SELECT THE ASSEMBLY SEQUENCE THAT BEST WORKS FOR YOU!

## ASSEMBLY STEPS:

**STEP 1A. SUB-ASSEMBLE EACH CROSSBOW WITH DESIRED ACCESSORIES FOR SECTIONS A.1 & A.2.**

**INSTRUCTIONS FOR EACH KIT CAN BE FOUND IN THEIR RESPECTIVE CARTON!**



## TABLE 1

### TOP OF CROSSBOW

#### COMPONENTS TO INSTALL

|     |            |                         |
|-----|------------|-------------------------|
| A.1 | HD UTILITY | - CONDUIT KIT OR BEACON |
|     | Grip-Lock  | - CONDUIT KIT OR BEACON |
|     | ProLift    | - CONDUIT KIT OR BEACON |


### BOTTOM OF CROSSBOW

#### COMPONENTS TO INSTALL

|     |            |                                                   |
|-----|------------|---------------------------------------------------|
| A.2 | HD UTILITY | - LADDER STOP, STROBE BRACKET, AND/OR REAR ROLLER |
|     | Grip-Lock  | - Grip-Lock SUB-ASSEMBLY                          |
|     | ProLift    | - DAMPER BRACKET                                  |

**STEP 1B. SUB-ASSEMBLE EACH CROSSBOW WITH DESIRED ACCESSORIES FOR SECTIONS B.1 & B.2.**

**INSTRUCTIONS FOR EACH KIT CAN BE FOUND IN THEIR RESPECTIVE CARTON!**



**TABLE 2**


| TOP OF CROSSBOW    |                       |                                             |
|--------------------|-----------------------|---------------------------------------------|
|                    | COMPONENTS TO INSTALL |                                             |
| <b>B.1</b>         | <u>HD UTILITY</u>     | - WEAR STRIP (MODIFY IF NECESSARY, TABLE 3) |
|                    | <u>Grip-Lock</u>      | - WEAR STRIP (MODIFY IF NECESSARY, TABLE 3) |
|                    | <u>ProLift</u>        | - INNER STOP POST                           |
| BOTTOM OF CROSSBOW |                       |                                             |
|                    | COMPONENTS TO INSTALL |                                             |
| <b>B.2</b>         | <u>HD UTILITY</u>     | - MOUNTING BRACKETS                         |
|                    | <u>Grip-Lock</u>      | - MOUNTING BRACKETS                         |
|                    | <u>ProLift</u>        | - MOUNTING BRACKETS                         |

**ALTER WEAR STRIP AND INSTALL ON CROSSBOW (IF APPLICABLE)! REFERENCE TABLE 3 BELOW FOR WEAR STRIP ALTERATION INSTRUCTIONS!**

**TABLE 3**

| ADDED ACCESSORIES        | ALTERATION FOR WEAR STRIP                              |
|--------------------------|--------------------------------------------------------|
| 4" UPRIGHT***            | REMOVE 2" FROM END OF WEAR STRIP                       |
| 4" PVC CONDUIT KIT       | REMOVE 7.25" FROM CENTER OF WEAR STRIP                 |
| 6" PVC CONDUIT KIT       | REMOVE 9.50" FROM CENTER OF WEAR STRIP                 |
| ALUMINUM BOX CONDUIT KIT | REMOVE 13.25" FROM CENTER OF WEAR STRIP                |
| BEACON                   | REMOVE 4" FROM CENTER OF WEAR STRIP                    |
| ProLift (SINGLE SIDE)    | CUT WEAR STRIP IN HALF, DO NOT INSTALL ON ProLift SIDE |
| ProLift (DUAL SIDE)      | DO NOT INSTALL WEAR STRIP                              |


**SLIDE WEAR STRIP INTO RAIL AND CENTER (1 PER CROSSBOW)**



**SLIDE ONE SIDE OF WEAR STRIP INTO CROSSBOW, THEN ROLL OTHER SIDE TO SNAP STRIP INTO PLACE**



**STEP 1C SUB-ASSEMBLE EACH CROSSBOW WITH  
DESIRED ACCESSORIES FOR SECTIONS C.1 & C.2**



**TABLE 4**

| TOP OF CROSSBOW    |                       |                              |
|--------------------|-----------------------|------------------------------|
|                    | COMPONENTS TO INSTALL |                              |
| C.1                | HD UTILITY            | - 4" UPRIGHT                 |
|                    | Grip-Lock             | - N/A                        |
|                    | ProLift               | - SLIDES FOR BASE EXTRUSION  |
| BOTTOM OF CROSSBOW |                       |                              |
|                    | COMPONENTS TO INSTALL |                              |
| C.2                | HD UTILITY            | - UPRIGHTS (6", 9", RATCHET) |
|                    | Grip-Lock             | - STROBES                    |
|                    | ProLift               | - STROBES                    |


**ASSEMBLY STEPS (FULL BENCH ASSEMBLY):**

- 2T. ADD DRIVELINES (IF INSTALLING ProLift)
- 3T. ADD HANDLES (IF INSTALLING Grip-Lock OR ProLift) AND DAMPERS (IF INSTALLING ProLift)
- 4T. ADD OUTER SUPPORT BARS (IF INSTALLING Grip-Lock OR ProLift)
- 5T. ADD STEP LADDER KIT (Grip-Lock OR ProLift ONLY!)

**6T. ASSEMBLE ENDS CAPS TO CROSSBOW**

USED FOR HD UTILITY &  
Grip-Lock RACKS

LOCATED IN CROSSBOW KIT



**7T. INSTALL ROOF RAIL KIT ON VEHICLE ROOF OR BOTTOM MOUNTING BRACKETS**

(ROOF RAIL KIT REQUIRED FOR Grip-Lock & ProLift  
OPTIONAL FOR HD UTILITY, NOT NEEDED FOR GM LADDER  
RACKS)

**8T. MOUNT CROSSBOW SUB-ASSEMBLIES FROM STEP 1 TO  
VEHICLE/MOUNTING BRACKET, OR ROOF RAIL  
(LOOSE INSTALL)**

**ALTERNATE ASSEMBLY METHOD!**  
**(ASSEMBLE ON VEHICLE ROOF):**

2R. INSTALL ROOF RAIL KIT ON VEHICLE ROOF OR BOTTOM MOUNTING BRACKETS

(ROOF RAIL KIT REQUIRED FOR Grip-Lock & ProLift, OPTIONAL FOR HD UTILITY, NOT NEEDED FOR GM LADDER RACKS)

3R. MOUNT CROSSBOW SUB-ASSEMBLIES FROM STEP 1 TO VEHICLE/MOUNTING BRACKET, OR ROOF RAIL (LOOSE INSTALL)

4R. ADD DRIVELINES (IF INSTALLING ProLift)

5R. ADD HANDLES (IF INSTALLING Grip-Lock OR ProLift) AND DAMPERS (IF INSTALLING ProLift)

6R. ADD OUTER SUPPORT BARS (IF INSTALLING Grip-Lock OR ProLift)


7R. ADD STEP LADDER KIT (Grip-Lock OR ProLift ONLY!)

8R. ASSEMBLE END CAPS TO CROSSBOW

USED FOR HD UTILITY &  
Grip-Lock RACKS

LOCATED IN CROSSBOW KIT

**FULLY TIGHTEN**  
**(2) FAS0473, 63851**  
**(2 PLACES PER END CAP)**  
**5/16" SOCKET**



USED FOR ProLift RACKS  
LOCATED IN ProLift Kit

