


White Noise Backup Alarm Kit - Colorado

CATALOG NUMBER

Wire Harness

69280

Backup Alarm



PRODUCT FEATURES

- This product is compatible with the Chevy Colorado.
- This kit includes a white noise backup alarm (61501) and a wire harness (64018).
- There are no OEM options required with this product.
- There are no OEM options this product is not compatible with.
- This product does not work for model years '23 & '24.

Model Year Validated:

2022

PURCHASED
COMPONENT
KEY FEATURES

DESCRIPTION OF REQUIREMENTS
DIMENSIONAL REQUIREMENTS (AS SHOWN ON DRAWING)
N/A
LOAD/RATING REQUIREMENT
N/A
MATERIAL REQUIREMENT
N/A
PACKAGING REQUIREMENT
N/A
OTHER REQUIREMENTS
Note: AAMP Part # BUA-97WNC



THIS DRAWING IS THE PROPERTY OF ADRIAN STEEL COMPANY AND IS NOT TO BE USED IN ANY MANNER
DETRIMENTAL TO THE INTERESTS OF ADRIAN STEEL COMPANY

TOLERANCES & INSPECTION

UNLESS OTHERWISE SPECIFIED		
ALL BEND ANGLES ARE 90 DEGREES		
ALL DIMENSIONS ARE IN INCHES.		
REFERENCE DIMENSIONS (X.XXX) DO NOT REQUIRE INSPECTION		
FEATURES	HOLES/SLOTS	ANGLES
0.0 = ± .125	0.0 = ± .062	0° = ± 2°
0.00 = ± .062	0.00 = ± .031	0.0° = ± 1°
0.000 = ± .031	0.000 = ± .015	
Material Thickness: per ASTM Std. Weld Callouts per AWS		

RELEASE & REVISIONS

INITIAL ECN:	23456
CURRENT ECN:	25415
ECN DESCRIPTION:	
Revise MPN on Alarm PPDS	
REVISED BY: JLT	


PURCHASED
COMPONENT

REFERENCED SUPPLIER AND/OR MANUFACTURER
AAMP
REFERENCED SUPPLIER AND/OR MANUFACTURER PART NUMBER
BUA-97WNC
COLOR (ONLY LIST IF COLOR SPECIFIC)
COMODITY ITEM (Y/N) (YES = ALL DIMENSIONS AND NOTES ARE REFERENCE) (NOTE: DIMENSIONS AND FEATURES MAY VARY FOR A COMODITY ITEM.)
NO

PRINTED DOCUMENT IS UNCONTROLLED

Sheet 1 of 1

PART / PRODUCT IDENTIFICATION

 ADRIAN STEEL®		ADRIAN STEEL COMPANY 906 JAMES STREET, ADRIAN, MI 49221	REVISION LEVEL A
MAT'L USED:		DESIGNED BY: PEN	
DESCRIPTION: B/U ALM, WHITE NOISE TR			
WEIGHT (Lbs.): 2	SEGMENT CODE: ELE	PART NUMBER: 61501	

PURCHASED
COMPONENT
KEY FEATURES

DESCRIPTION OF REQUIREMENTS
DIMENSIONAL REQUIREMENTS (AS SHOWN ON DRAWING)
N/A
LOAD/RATING REQUIREMENT
N/A
MATERIAL REQUIREMENT
N/A
PACKAGING REQUIREMENT
N/A
OTHER REQUIREMENTS
Plug & play harness, does not include alarm.
2020 MDY No vehicle options required



THIS DRAWING IS THE PROPERTY OF ADRIAN STEEL COMPANY AND IS NOT TO BE USED IN ANY MANNER
DETRIMENTAL TO THE INTERESTS OF ADRIAN STEEL COMPANY

TOLERANCES & INSPECTION

UNLESS OTHERWISE SPECIFIED		
ALL BEND ANGLES ARE 90 DEGREES		
ALL DIMENSIONS ARE IN INCHES.		
REFERENCE DIMENSIONS (X.XXX) DO NOT REQUIRE INSPECTION		
FEATURES	HOLES/SLOTS	ANGLES
0.0 = ± .125	0.0 = ± .062	0° = ± 2°
0.00 = ± .062	0.00 = ± .031	0.0° = ± 1°
0.000 = ± .031	0.000 = ± .015	
Material Thickness: per ASTM Std. Weld Callouts per AWS		

RELEASE & REVISIONS

INITIAL ECN:	24579
CURRENT ECN:	25280
ECN DESCRIPTION:	
Scan supplier's print	
REVISED BY: AMB	


PURCHASED
COMPONENT

REFERENCED SUPPLIER AND/OR MANUFACTURER
AAMP
REFERENCED SUPPLIER AND/OR MANUFACTURER PART NUMBER
P-BUA-COLORADO
COLOR (ONLY LIST IF COLOR SPECIFIC)
COMODITY ITEM (Y/N) (YES = ALL DIMENSIONS AND NOTES ARE REFERENCE) (NOTE: DIMENSIONS AND FEATURES MAY VARY FOR A COMODITY ITEM.)
YES

PRINTED DOCUMENT IS UNCONTROLLED

Sheet 1 of 1


PART / PRODUCT IDENTIFICATION

 ADRIAN STEEL®		ADRIAN STEEL COMPANY 906 JAMES STREET, ADRIAN, MI 49221		REVISION LEVEL A
MAT'L USED:			DESIGNED BY: A. BUSSING	
DESCRIPTION: HARN, BUA CO				
WEIGHT (Lbs.): 1.0		SEGMENT CODE: ALA		PART NUMBER: 64018


Revisions			
Rev.	Date	Author	Description
1	3/17/2020	Bennet Fisher	Initial Drawing
2	4/6/2020	Bennet Fisher	Changed all wire between connectors to 18 Gauge
3	10/29/2020	Bennet Fisher	Updated Female connector contacts

Coverings	
Id	Assembly
[35]	
[36]	

From	To	Color	Gauge
C1.1	S1	Green	18 AWG
C1.2	C2.2	Brown	18 AWG
C1.3	C2.3	Yellow	18 AWG
C1.4	S2	Black	18 AWG



From	To	Color	Gauge
C2.1	S1	Green	18 AWG
C2.2	C1.2	Brown	18 AWG
C2.3	C1.3	Yellow	18 AWG
C2.4	S2	Black	18 AWG




From	To	Color	Gauge
C3.1	S1	Red	18 AWG
C3.2	S2	Black	18 AWG



Notes	
①	Cover wiring with cloth tape; leave 1/2" of exposed wiring behind connector
②	Lock tape split loom behind C3

Title	----	Part Number	P-BUA-COLORADO_	Revision	----
Description	2020 Chevrolet Colorado Backup Alarm Harness			QA	----

Drawn By	----	Name	----	Date	----
Eng Approved	----				
Mfg Approved	----				
QA	----				



This document contains confidential and proprietary information that cannot be reproduced or divulged, in whole or in part, without written authorization.

“Compare Installation Instructions that come with the Product to Installation Instructions in ASCO System for accuracy.”



P-BUA-COLORADO

Wiring Harness for Backup Alarm 2016-2021 Chevrolet Colorado

INSTALLATION MANUAL





Thank you for purchasing the **P-BUA-COLORADO**

Table of Contents

Page 3 - Tools Required For Installation

WHAT'S INCLUDED:

- Vehicle Specific Wire Harness (P-BUA-COLORADO)

COMPATIBLE ACCESSORIES:

- 97dB Backup Alarm (BUA-97C)
- 97dB White Noise Backup Alarm (BUA-97WNC)



TOOLS REQUIRED:



1. 10mm Nut-setter
2. Impact Drill

STEP 1:

Locate the OEM tail lamp connector that is below the truck's driver side tail lamp
- The connector is accessible from the underside of the truck



STEP 2:

Unplug the OEM connector



STEP 3:

Install the P-BUA-COLORADO harness between the two OEM connectors



STEP 4:

Use an impact drill and 10mm nut-setter to install a compatible backup alarm on the metal surface near the tail lamp connector
Note: (2) 10mm TEK screws are provided with the compatible backup alarm



STEP 5:

Plug the backup alarm connector into the mating connector on the P-BUA-COLORADO harness

STEP 6:

Enter the Vehicle Settings menu through the driver's information center

- Change the remote entry exterior lighting to "off"
 - This will prevent the backup alarm from sounding when the vehicle is unlocked with the OEM keyless entry transmitter

STEP 7:

Test the backup alarm




Phone – 866-766-2267

E-Mail – support@aampglobal.com



EchoMaster is a Power Brand of AAMP Global

EchoMaster.com



OEM tail lamp connection
and backup alarm placement
are below driver side tail lamp

Access from underside of vehicle

