


## Large Caulk Holder 10.58”H X 23”W



**PRODUCT WEIGHT**

**7.5 LBS**

**WIDTH x DEPTH x HEIGHT**

**23” X 4.39” X 10.58”**

**CAPACITY**

**7 - 2.75 DIAMETER  
TUBES**

**COLOR**

**GRAY**

**CATALOG NUMBER**


**CHL7**

**PRODUCT FEATURES**

**Large caulk holder that holds 7 industrial size caulk tubes 2.75” diameter or smaller. Foam tape along bottom edge provides noise reduction. It is designed to be used in areas such as back doors, partition, etc.**

INSTR. NUMBER	PG:	REV:	ITEM NO.	PART NUMBER	DESCRIPTION	
: <b>65532</b>	<b>1</b>	<b>A</b>	1	65525-G	LARGE CAULK HOLDER 14", GRAY	1
			2	26650-0	Foam Tape, 0.25x2.5x40.0	1
PART NUMBER : <b>CHL7 &amp; CHS8</b>			3	BAG65529	Bag For Short Caulk Holders	1
PART • CAULK HOLDER, LARGE 7-DESC. • HOLE 23"			4	65527	Install Instr. For CHL4 & CHS5	1

**CHS8 PART NUMBER IS 65530-G**



**GET TO KNOW THE VEHICLE** - AT THE BEGINNING OF ANY INSTALLATION, CHECK THE LOCATION OF THE FUEL TANK, FUEL LINES, BRAKE LINES, HIGH VOLTAGE BATTERIES AND WIRING HARNESSSES TO AVOID INJURY OR PROPERTY DAMAGE FROM TOOL CONTACT.

**SEAL ALL EXTERIOR HOLES** - ALL INSTALLATION HOLES SHOULD BE SEALED WITH BUTYL TAPE OR SILICON TO PREVENT WATER AND EXHAUST GASES FROM ENTERING THE VEHICLE.

**CONTROL DRILL DEPTH** - TO AVOID DAMAGE TO THE VEHICLE, USE A DRILL STOP OR CLEARED STEP BIT WHEN DRILLING INSTALLATION HOLES.

**ALWAYS ADD PRIMER** - WHEN ADDING INSTALLATION HOLES BE SURE TO USE A SELF-ETCHING PRIMER TO PREVENT CORROSION, FASTENER FAILURE AND INJURY.

**MOUNTING POINTS MUST HAVE METAL-TO-METAL CONTACT** - USE PROVIDED MOUNTING SPACERS TO ACCOMMODATE FOR VEHICLE FEATURES, CARPET OR SUBFLOORS.


**PROVIDE CLEARANCE FOR SPACERS** - IF THE INSTALLATION VEHICLE CONTAINS A CARPET OR SUBFLOOR, USE A 1-3/16" DIAMETER CARPET CUTTER (P/N: 31183-0) AT ALL MOUNTING LOCATIONS TO OPEN UP ROOM FOR SPACERS.

**CHECK SPACER ORIENTATION** - BE SURE THAT THE INDENT IN THE SPACER COVERS THE PLUSNUT HEAD; THIS ENSURES THE MOST METAL-TO-METAL CONTACT AND REDUCES VIBRATION.


**PLUSNUT INSTALLATION** - A PLUSNUT GUN IS RECOMMENDED FOR PLUSNUT INSTALLATION FOR ITS PRODUCTION SPEED. HOWEVER, A PLUSNUT SETTING TOOL CAN ALSO BE USED (P/N: 22200-0).

**THRU-BOLT CLEARANCE** - WHEN USING A THRU-BOLT AT ANY MOUNTING LOCATION, BE SURE THAT YOUR HOLE HAS 1/16" CLEARANCE.

**FASTENERS USED**



FAS0438  
5/16-18X.75 ZP  
SCREW, HFLNG  
QTY: 6



FAS0135  
5/16-18 ZN  
NUT, HEX FLNG  
QTY: 6

**BEGIN ASSEMBLY**

**STEP 1 - CUT FOAM STRIP TO 23" & INSTALL ON BOTTOM LIP**



**26650-0  
SCISSORS**

**STEP 2 - INSTALL HOLDER TO DOOR PANEL, PARTITION, ETC**

**6 PLACES  
FAS0438  
FAS0135  
11/32 DRILL**

**DRILL HOLES & INSTALL  
FASTENERS IN END  
PANEL, PARTITION, ETC**

