




Introduction / Comments:

This street side (drivers) e-track kit is designed to fit the 2014 Promaster 159" Extended High Roof.

Note:

It is advised that all fasteners used in this assembly and installation should be checked for tightness at the following intervals: @ 2-weeks and again @ 6-weeks of operation. This preventive maintenance step must be completed to ensure your Partition gives you long service




E-Track Kit (Street Side) 2014 Promaster 159" Extended High Roof vehicle ET159PMEXS



- PRECAUTIONS -

**CAUTION**

**THE USE OF AIR IMPACT TOOLS CAN
OVER-TORQUE FASTENERS AND
CAUSE FASTENER FAILURE!**

**CAUTION**

**ALL INSTALLATION HOLES SHOULD BE SEALED
WITH SILICON OR BUTYL SEALANT TO PREVENT
EXHAUST FUMES FROM ENTERING THE VEHICLE!**

**DANGER**

**INSPECT FOR FUEL TANK, FUEL LINES, BRAKE LINES, HIGH
VOLTAGE BATTERIES AND ELECTRICAL LINES PRIOR TO
DRILLING TO AVOID DAMAGING CRITICAL VEHICLE SYSTEMS
OR INJURY TO INSTALLER DURING INSTALLATION PROCESS!**

**CAUTION**

**TO AVOID DAMAGING THE VEHICLE ALWAYS
USE DRILL STOPS WHEN DRILLING ANY IN-
STALLATION HOLES!**




- IMPORTANT WARRANTY REQUIREMENTS -

1. SUBSTITUTING ADRIAN STEEL SPECIFIED FASTENERS FOR ASSEMBLY AND/OR INSTALLATION WILL VOID YOUR PRODUCT WARRANTY.
2. ALL HOLES DRILLED INTO VEHICLE SHOULD HAVE THE RAW METAL EDGES SEALED WITH A SELF-ETCHING PRIMER TO RESIST CORROSION AND POTENTIAL FASTENER POINT FAILURE.
3. ALL FASTENERS USED IN THE INSTALLATION OF THIS PRODUCT SHOULD BE TIGHTENED TO THE TORQUE(S) SPECIFIED IN THESE INSTRUCTIONS.
4. THESE INSTRUCTIONS SHOULD BE KEPT WITH THE VEHICLE.

THE BASIC TOOLS NEEDED FOR MOST INSTALLATIONS



DRILL

DRILL BIT WITH
STOPRATCHET, SOCKETS
AND/OR WRENCHES

SCREWDRIVERS



MEASURING TAPE


ADDITIONAL TOOLS MAY BE NEEDED FOR THIS INSTALLATION AND THEY WILL BE IDENTIFIED IN THE STEPS THAT FOLLOW.



If your vehicle contains carpet or a rubber floor mat you will need to prepare the mounting location. Position the product to be installed into the vehicle and once you are satisfied with the mounting locations, mark the mounting locations. Using a 1-3/16" diameter carpet cutter (P/N: 31183-0). Select the appropriate floor spacers as shown in the illustration. Set those aside for use later into the installation process. Using the correct drill bit size for the selected plusnut, drill the mounting holes in the vehicle sheet metal to prepare for installing the plusnuts.

If you are thru-bolting at any of the locations simply drill a hole that is 1/16" larger than the bolt size(s) for those locations.

Once you have drilled the holes into the vehicle, the raw metal edges should be sealed using a self-etching primer to resist corrosion and potential fastener point failure.




A PLUSNUT (RIVNUT) SETTING TOOL IS REQUIRED FOR PLUSNUT (RIVNUT) INSTALLATION AND IS SUPPLIED WITH THIS KIT. OR USE AN AIR POWERED PLUSNUT SETTING GUN.

1/4-20UNC Plusnut (FAS0052) Use 3/8" dia. drill w/stop

FAS0080 SCREW, HXHD, 1/4-20UNCx2.00", G8
 FAS0067 WASHER, FLAT, 1/4"ID
 22200-0 PLUSNUT TOOL

5/16-18UNC Plusnut (FAS0091) Use 1/2" dia. drill w/stop

FAS0095 SCREW, HXHD, 5/16-18UNCx2.00", G8
 FAS0086 WASHER, FLAT, 5/16"ID
 22200-0 PLUSNUT TOOL




Place barrel of the plusnut body in sheet metal thru hole until flange is flush with sheet metal.

Using a 9/16" combination wrench of plusnut tool body and a second hand wrench, ratchet, or air tool, rotate the hex bolt head CW to draw plus nut flanges up (set the plusnut).


Installation and/or Assembly Fasteners**BAG49473**

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	BAG0507-A	5" x 7" 3MIL AUTOBAG	1
2	FAS0055	Nut, Hex Flange, Nylock 1/4-20	22
3	FAS0060	Washer, Lock, Split, 1/4	30
4	FAS0067	Washer, Flat, 1/4	22
5	03927-1	Floor Spacer Short	1
6	FAS0078	Screw, Hex Hd, 1/4-20x1.00 Zn Plate, Grade 8	48
7	FAS0052	Plusnut, 1/4	30







Individual Fasten Identification Sheet




FAS0055
Nut, HxFIng,
Nylon Lock,
1/4-20UNC




FAS0060
Washer, SplitLock,
1/4" ID



FAS0067
Washer, Flat, 1/4"ID
5/16 ID x 0.734" OD
x .065



FAS0052
Plusnut, PreBulbed,
5/16-18UNC




03927-1
Spacer, Floor,
11/32"



FAS0078
Screw, Hx Hd,
1/4-20UNC x 1"



Installation and/or Assembly Hardware




45030-G
E-TRACK, CUT TO 48”
Qty = 1

45031-G
E-TRACK, CUT TO 52”
Qty = 1

29687-0
E-TRACK, CUT TO 92”
Qty = 1

29687
E-TRACK, CUT TO 91”
Qty = 1




45594-G
BRACKET, CENTER SUPPORT,
E-TRACK, PROMASTER
Qty = 7

***** WARNING *****

E-TRAC TIE DOWN
WEIGHT IS LIMITED TO
200 LBS.

23916-0
WARNING LABEL, E-TRACK
Qty = 4



45593-G
BRACKET, END SUPPORT,
E-TRACK, PROMASTER
Qty = 4




23896-0
E-TRACK, STRAP, 12”
W/CAM BUCKLE
Qty = 4




Step 01 Introduction Statement

Installation of ET159PMESS will involve attaching four separate track sections in suggested order listed below, but can be rearranged at any time. During installation please make use of the information in the beginning section of these instructions describing plusnut installation and all associated caution/warning notes.







Step 02 Location & Installation of the Front Lower E-Track Section




Position e-track section (45030-G) between the street side "B-Pillar" and "C-Pillar" as shown at left. Centerline of the e-track to be 21 inches above the vehicle floor. Check both ends centerline dimensions prior to marking the four mounting holes marks in the center left and right detail views. Use permanent marker pen. Once all four holes have been marked set e-track section aside.



Mark/Drill
4-pl



Install four 1/4-20UNC plusnuts (FAS0052) in marked holes, use a 3/8" diameter drill bit with a stop collar when drilling plusnut holes. See front of this instruction for proper plusnut installation.




FAS0052
2-pl

Once all four plusnuts have been installed, reposition the e-track section and secure in place with four of the following fasteners.

Note

Fasteners to be hand tight only.

FAS0060
FAS0078
2-pl



FAS0052
2-pl

FAS0060
FAS0078
2-pl




Step 02 Location & Installation of the Front Lower E-Track Section, continued

Position the Center E-Track Support Bracket (45594-G) as shown in figure at right. Secure bracket to e-track section with two each of the fasteners listed.

Note

Fasteners to be hand tight only

Mark the center bracket plusnut locations using a permanent marker pen. Once both holes have been marked remove fasteners at each end of the e-track section and set aside at this time.




Install two 1/4-20UNC plusnuts (FAS0052) in marked holes, use a 3/8" diameter drill bit with a stop collar when drilling plusnut holes. See front of this instruction proper installation.

Once both plusnuts have been installed, reposition the e-track section and secure both ends to the "B" and "C" pillars. Next secure the center support bracket in place with two each of the listed fasteners.




Note

Tighten all fasteners, proceed to next step.



FAS0060
FAS0078
Typ

FAS0067
FAS0060
FAS0078
2-pl






Step 03 Location & Installation of the Front Upper E-Track Section and Brackets

Secure two end support brackets (45593-G) to the e-track section (45031-G) as shown in views below. Secure brackets to the e-track section with six of the listed fasteners.

Note

Fasteners to be hand tight only






Step 03 Location & Installation of the Front Upper E-Track and Brackets, continued


Install two 1/4-20UNC plusnuts (FAS0052) in indicated holes in the street side “C-Pillar” , use a 3/8” diameter drill bit with a stop collar when enlarging existing OEM sheet metal holes shown in the right hand view.


See front of this instruction for proper plusnut installation.



Install two 1/4-20UNC plusnuts (FAS0052) in indicated holes in the street side “B-Pillar” , use a 3/8” diameter drill bit with a stop collar when enlarging existing OEM sheet metal holes shown in the right hand view.

See front of this instruction for proper plusnut installation.





**Step 03 Location & Installation of the Front Upper E-Track and Brackets, continued**

Position upper front e-track (45031-G) section (from pp 10) between the street side “B-Pillar” and “C-Pillar” as shown in views. Centerline of the e-track to be approx. 41 inches above the vehicle floor. Secure the end brackets to the “B-Pillar” and “C-Pillar” as shown in bottom two detail views. Use four of each of the fasteners listed below to secure brackets to the street side “B & C Pillars”.

Note

E-track section has been removed from bottom views for clarity to show fastener locations



**Step 03**
ued**Location & Installation of the Front Upper E-Track and Brackets, contin-**45031-G
E-Track,
52" lg


Position the Center E-Track Support Bracket (45594-G) as shown in figure at right.

Note

Fasteners should be hand tight only

Mark the center bracket plusnut locations using a permanent marker pen. Once both holes have been marked remove fasteners at each end of the e-track section to the end support brackets and set aside at this time.





Install two 1/4-20UNC plusnuts (FAS0052) in marked holes, use a 3/8" diameter drill bit with a stop collar when drilling plusnut holes. See front of this instruction proper installation.

45031-G
E-Track, 52"

Once both plusnuts have been installed, reposition the e-track section and secure both ends to the "B" and "C" pillars. Next secure the center support bracket in place with two each of the listed fasteners.

Note


Tighten all fasteners, proceed to next step.

FAS0052
2-plFAS0067
FAS0060
FAS0078
2-plFAS0055
FAS0078
typ



Step 04 Location & Installation of the Lower Rear E-Track Section and Brackets


Position e-track section (29687-0 CUT TO 91") between the street side "C-Pillar" and "D-Pillar" as shown at below. Centerline of the e-track to be 21 inches above the vehicle floor. Check both ends centerline dimensions prior to marking the four mounting holes marks in left and right details views shown below. Use permanent marker pen. Once all four holes have been marked set e-track section aside. **Please note orientation of e-track section (29687-0) as shown in middle two views. Proper orientation ensures proper e-track to bracket mounting hole alignments.**





Step 04 Location & Installation of the Lower Rr E-Track Sand Brackets, continued

Street Side
D-Pillar



Street Side
C-Pillar


Position two Center E-Track Support Bracket (45594-G) as shown in figure at right. Secure bracket to e-track section with two each of the fasteners listed.

Note


Fasteners to be hand tight only

Mark the center bracket plusnut locations using a permanent marker pen. Once both holes have been marked remove fasteners at each end of the e-track section and set aside at this time.

Mark/Drill
2-pl



FAS0052
2-pl




29687-0

FAS0055
FAS0078
2-pl


Install two 1/4-20UNC plusnuts (FAS0052) in marked holes, use a 3/8" diameter drill bit with a stop collar when drilling plusnut holes. See front of this instruction proper installation.

Once all four plusnuts have been installed, reposition the e-track section and secure both ends to the "B" and "C" pillars. Next secure the center support bracket in place with two each of the listed fasteners.


Note



FAS0060
FAS0078
2-pl




FAS0067
FAS0060
FAS0078
4-pl



03927-1
1-pl


FAS0060
FAS0078
2-pl






Step 05 Location & Installation of the Upper Rear E-Track Section and Brackets

Secure two end support brackets (45593-G) to the e-track section (29687-0 CUT TO 92") as shown in views below. Secure brackets to the e-track section with six of the listed fasteners. **Please note orientation of e-track section (29687-0) as shown in middle two views. Proper orientation ensures proper e-track to bracket mounting hole alignments.**




**Step 05 Location & Installation of the Upper Rr E-Track Section and Brackets, continued**

Position e-track section (29687-0) between the street side "C-Pillar" and "D-Pillar" as shown at left. Centerline of the e-track to be 41 inches above the vehicle floor.


Check both ends centerline dimensions prior to marking the four end support brackets (45593-G & 45594-G) mounting holes marks in the details views shown below.

Please note that in lower two detail views the lower plusnut location is hidden in view. Use permanent marker pen to mark all four mounting locations. Once all four holes have been marked set e-track section aside.



Mark/Drill
4-pl

Install four 1/4-20UNC plusnuts (FAS0052) in marked holes, use a 3/8" diameter drill bit with a stop collar when drilling plusnut holes. See front of this instruction for proper plusnut installation.






Step 05 Location & Installation of the Upper Rr E-Track Section and Brackets, continued

Position two of the Center E-Track Support Bracket (45594-G) as shown in figure at right.


Note

Fasteners should be hand tight only

Mark the center bracket plusnut locations using a permanent marker pen. Once all four holes have been marked remove fasteners at each end of the e-track section to the end support brackets and set aside at this time.



Install six 1/4-20UNC plusnuts (FAS0052) in marked holes, use a 3/8" diameter drill bit with a stop collar when drilling plusnut holes. See front of this instruction proper installation.




29687-0
E-Track, CUT TO 92"

Once both plusnuts have been installed, reposition the e-track section and secure both ends to the "B" and "C" pillars. Next secure the center support bracket in place with two each of the listed fasteners.


Note

Tighten all fasteners, proceed to next step.




FAS0067
FAS0060
FAS0078
6pl

FAS0055
FAS0078
2-pl




FAS0055
FAS0078
6-pl

FAS0055
FAS0078
2-pl





Step 06 Apply warning labels and straps



PURCHASED COMPONENT KEY FEATURES	
DESCRIPTION OF REQUIREMENTS	
DIMENSIONAL REQUIREMENTS (AS SHOWN ON DRAWING)	
N/A	
LOAD/RATING REQUIREMENT	
N/A	
MATERIAL REQUIREMENT	
N/A	
PACKAGING REQUIREMENT	
N/A	
OTHER REQUIREMENTS	
2" x 12' STRONG POLYESTER WEBBING WITH 48" FIXED END - DESIGNED TO SECURE CARGO UP TO 833 LBS. 2" CAM BUCKLE WITH SPRING-ACTUATED E-FITTINGS ON BOTH ENDS	



THIS DRAWING IS THE PROPERTY OF ADRIAN STEEL COMPANY AND IS NOT TO BE USED IN ANY MANNER DETRIMENTAL TO THE INTERESTS OF ADRIAN STEEL COMPANY		PRINTED DOCUMENT IS UNCONTROLLED		Sheet 1 of 1	
TOLERANCES & INSPECTION		PART / PRODUCT IDENTIFICATION			
UNLESS OTHERWISE SPECIFIED ALL BEND ANGLES ARE 90 DEGREES ALL DIMENSIONS ARE IN INCHES. REFERENCE DIMENSIONS (X.XXX) DO NOT REQUIRE INSPECTION		ADRIAN STEEL® ADRIAN STEEL COMPANY 906 JAMES STREET, ADRIAN, MI 49221		REVISION LEVEL B	
FEATURES 0.0 = ± .125 0.00 = ± .062 0.000 = ± .031		HOLES/SLOTS 0.0 = ± .062 0.00 = ± .031 0.000 = ± .015		ANGLES 0° = ± 2° 0.0° = ± 1°	
Material Thickness: per ASTM Std. Weld Callouts per AWS		MAT'L USED: POLYESTER DESIGNED BY: RG			
RELEASE & REVISIONS		DESCRIPTION: E-TRAC,STRAP 12'W/CAM BKL			
INITIAL ECN: 4100		WEIGHT (Lbs.): 1.60 LBS		SEGMENT CODE: MAC	
CURRENT ECN: 25465		PART NUMBER: 23896-0			
ECN DESCRIPTION:		COMODITY ITEM (Y/N) (YES = ALL DIMENSIONS AND NOTES ARE REFERENCE) (NOTE: DIMENSIONS AND FEATURES MAY VARY FOR A COMODITY ITEM.) YES			
CREATED PPDS SHEET FOR 23896-0		PURCHASED COMPONENT			
REVISED BY: WJA		REFERENCED SUPPLIER AND/OR MANUFACTURER AUSTIN HARDWARE / OR EQUIVALENT			
		REFERENCED SUPPLIER AND/OR MANUFACTURER PART NUMBER CCCS-001			
		COLOR (ONLY LIST IF COLOR SPECIFIC) N/A			

ITEM DESCRIPTION: E-TRAC 128" OR 10'8"



MANUFACTURER: CARGOWALL LIMITED
MANUFACTURERS PART NUMBER: TR1250H1008GYCN

SPECIFICATIONS: E-TRAC PURCHASED TO LENGTH
128" OR 10' 8"

SPECIAL NOTES: GREY POWDERCOAT

SUPPLIED BY: THIS ITEM IS ADRIAN SUPPLIED!

PURCHASED PRODUCT DATA SHEET (PPDS)

THIS DRAWING/INFORMATION IS THE PROPERTY OF ADRIAN STEEL COMPANY AND IS NOT TO BE USED IN ANY MANNER THAT IS DETRIMENTAL TO THE INTEREST OF ADRIAN STEEL. COPYRIGHTS AND OR PATENTS THAT MAY BE THE PROPERTY OF APPLICABLE OWNERS MAY PROTECT INFORMATION AND/OR DRAWINGS OF SUPPLIED PRODUCTS.



ADRIAN STEEL

Cargo Management Solutions for Commercial Vehicles

906 JAMES STREET
ADRIAN, MI 49221
517-265-6194

WWW.ADRIANSTEEL.COM

⚠ CAUTION ⚠

WHEN INSTALLING EQUIPMENT IN OR ON VEHICLES CHECK FOR FUEL TANKS, FUEL LINES, CONTROL LINES AND ELECTRICAL WIRING BEFORE DRILLING! ALWAYS USE DRILL BITS WITH INTEGRAL STOPS WHENEVER POSSIBLE!

DRAWN BY
B. HENSON

DATE DRAWN
12/11/10

ECN NUMBER
13546

ECN DATE
12/13/10

PART WEIGHT
17.46 LBS.

REV. LEVEL
B

PART NUMBER

29687-0