


FLOOR PLATE KIT,5274,FTM



PRODUCT WEIGHT
86.26 LBS

WIDTH x DEPTH x HEIGHT
N/A

CAPACITY
N/A

COLOR
BLACK

CATALOG NUMBER
FPK5274FTM

PRODUCT FEATURES

This kit is designed to be installed in the Ford E-Transit 148" wheel-base with a medium or high roof. It can also be used in place of the lower mounting rail in the gas Transit as a no-drill solution. These plates include hardware to mount the interior packages 5274TM and 5274TH without drilling into the floor of the high voltage electric vehicle.

SEE PAGE 2 FOR APPLICATION NOTES AND ACCESSORIES, OTHER PRODUCTS THAT WORK WITH THIS UNIT.



CATALOG NUMBER FPK5274FTM

PRODUCT APPLICATION

This kit is designed to be installed in the Ford E-Transit 148" wheel-base with a medium or high roof. It can also be used in place of the lower mounting rail in the gas Transit as a no-drill solution.


ACCESSORIES THAT WILL WORK WITH THIS PRODUCT

<i>CATALOG NUMBER</i>	<i>DESCRIPTION</i>
MD608PM	WRKBNCH MDLE,PM,18X34X84
MD506PM	DRW MODULE,CRBSD, PROMSTR
17A	CATALOG FILE 6 SHELF
5274TM	LOCKSMITH PKG,TRANSIT MR
5274TH	LOCKSMITH PKG,TRANSIT HR


SPECIAL APPLICATION NOTES

INSTR. NUMBER	: 65481	PG: 1	REV: G
PART NUMBER	: FORD TRANSIT FPK'S		
PART DESC.	: ASM INS, TRANSIT FLR PLATE		

PASSENGER
SIDE




DRIVERS
SIDE



INSTR. NUMBER : 65481	PG: 2	REV: E
PART NUMBER : FORD TRANSIT FPK'S		
PART • ASM INS,TRANSIT FLR PLATE DESC. •		


FPK130FTL

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	66495-B	FLR PLT,PS RR,FTL 130, BLACK	1
2	66494-B	FLR PLT,DS RR,FTL 130, BLACK	1
4	66884-B	FLR PLATE,PS D ANCHOR, BLACK	1
5	66493	FLR PLT,DS FR,FTL 130	1




FPK130FTM

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	66533-B	FLR PLT,PS RR,FTM 130, BLACK	1
3	66532-B	FLR PLT,DS RR,FTM 130, BLACK	1
5	66884-B	FLR PLATE,PS D ANCHOR, BLACK	1
6	66534-G	PASS. FRT. UPPER SHELF BRACKET, GRAY	1




FPK148FTL

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	66501-B	FLR PLT,PS FR,FTL 148, BLACK	1
2	66769-B	FLR PLT,DS RR,FTL 148, BLACK	1
3	66770-B	FLR PLT,PS RR,FTL 148, BLACK	1
4	65475-B	FLR PLATE, LINK	2
6	66884-B	FLR PLATE,PS D ANCHOR, BLACK	1
7	66555-B	FLR PLT,DS CTR,FT M/H 148	1



FPK148FTM


ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	66556-B	FLR PLT,DS RR,FT M/H 148	1
2	66491-B	FLR PLT,PS FR,FT M/H 148	1
3	66492-B	FLR PLT,PS RR,FT M/H 148	1
4	66555-B	FLR PLT,DS CTR,FT M/H 148	1
5	65475-B	FLR PLATE, LINK	2
6	66884-B	FLR PLATE,PS D ANCHOR, BLACK	1



INSTR. NUMBER	: 65481	PG: 3	REV: E
PART NUMBER	: FORD TANSIT FPK'S		
PART DESC.	• ASM INS, TRANSIT FLR PLATE		


FPK148MDS

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	66556-B	FLR PLT,DS RR,FT M/H 148	1
2	66555-B	FLR PLT,DS CTR,FT M/H 148	1
3	65475-B	FLR PLATE, LINK	1




FPK148XFTH

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	66498-B	FLR PLT,DS RR,FTH 148X, BLACK	1
2	66499-B	FLR PLT,PS RR,FTH 148X, BLACK	1
3	66555-B	FLR PLT,DS CTR,FT M/H 148	1
5	66491	FLR PLT,PS FR,FT M/H 148	1
6	65475	FLR PLATE, LINK	2




FPK5274FTL

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	66815-B	FLR PLT,PS RR,5274FTL	1
2	66816-B	FLR PLT,DS FR,5274FTL	1
3	66817-B	FLR PLT,DS RR,5274FTL	1
4	65475-B	FLR PLATE, LINK	1
6	66884-B	FLR PLATE,PS D ANCHOR, BLACK	1



FPK5274FTM


ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	66765-B	FLR PLT,DS CTR,FT M/H148, BLACK	1
2	66766-B	FLR PLT,DS RR,FT MH148, BLACK	1
3	66768-B	FLR PLT,PS RR,FT M/H148, BLACK	1
5	66884-B	FLR PLATE,PS D ANCHOR, BLACK	1



INSTR. NUMBER	: 65481	PG: 4	REV: E
PART NUMBER	: FORD TRANSIT FPK'S		
PART DESC.	: ASM INS, TRANSIT FLR PLATE		


FPK7016FTL

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	72521-B	FLR PLT,DS RR,FTL 130, BLACK	1
2	72522-B	FLR PLT,DS RR,FTL 130, BLACK	1
3	72523-B	FLR PLT,PS RR,FTL 130, BLACK	1



74131

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	74056	FLR PLT, DS RR, FTL 148	1
2	74057	FLR PLATE, DS FRT, FT148	1
3	71640-B	FLOOR PLATE ATTACHMENT BRACKET, BLACK	4
4	74058-B	FLR PLATE, PS REAR, FT148, BLACK	1
5	65475	FLR PLATE, LINK	1
6	66884	FLR PLATE,PS D ANCHOR	1



GET TO KNOW THE VEHICLE - AT THE BEGINNING OF ANY INSTALLATION, CHECK THE LOCATION OF THE FUEL TANK, FUEL LINES, BRAKE LINES, HIGH VOLTAGE BATTERIES AND WIRING HARNESSSES TO AVOID INJURY OR PROPERTY DAMAGE FROM TOOL CONTACT.

SEAL ALL EXTERIOR HOLES - ALL INSTALLATION HOLES SHOULD BE SEALED WITH BUTYL TAPE OR SILICON TO PREVENT WATER AND EXHAUST GASES FROM ENTERING THE VEHICLE.

CONTROL DRILL DEPTH - TO AVOID DAMAGE TO THE VEHICLE, USE A DRILL STOP OR CLEARED STEP BIT WHEN DRILLING INSTALLATION HOLES.

ALWAYS ADD PRIMER - WHEN ADDING INSTALLATION HOLES BE SURE TO USE A SELF-ETCHING PRIMER TO PREVENT CORROSION, FASTENER FAILURE AND INJURY.

MOUNTING POINTS MUST HAVE METAL-TO-METAL CONTACT - USE PROVIDED MOUNTING SPACERS TO ACCOMMODATE FOR VEHICLE FEATURES, CARPET OR SUBFLOORS.

PROVIDE CLEARANCE FOR SPACERS - IF THE INSTALLATION VEHICLE CONTAINS A CARPET OR SUBFLOOR, USE A 1-3/16" DIAMETER CARPET CUTTER (P/N: 31183-0) AT ALL MOUNTING LOCATIONS TO OPEN UP ROOM FOR SPACERS.


CHECK SPACER ORIENTATION - BE SURE THAT THE INDENT IN THE SPACER COVERS THE PLUSNUT HEAD; THIS ENSURES THE MOST METAL-TO-METAL CONTACT AND REDUCES VIBRATION.

PLUSNUT INSTALLATION - A PLUSNUT GUN IS RECOMMENDED FOR PLUSNUT INSTALLATION FOR ITS PRODUCTION SPEED. HOWEVER, A PLUSNUT SETTING TOOL CAN ALSO BE USED (P/N: 22200-0).


THRU-BOLT CLEARANCE - WHEN USING A THRU-BOLT AT ANY MOUNTING LOCATION, BE SURE THAT YOUR HOLE HAS 1/16" CLEARANCE.

FASTENERS THAT MAY BE USED


FAS0413
SCREW,PHT
M12 X 36 ZP,TRI




FAS0678
WASHER,LCK SPLIT
1/2 ZN




FAS0334
WASHER,FLAT
1/2 SS




FAS0408
SCREW,HH
7/16-20 X 1.632



FAS0661
BOLT,CRG
5/16-18X.75 G5ZN




FAS0557
WASHER,RET
5/16X.74 NY WH



FAS0440
NUT,HEX NLK FLG
5/16-18ZP




FAS0668
SCREW,BHCS
5/16-18X.75 SS




FAS0588
WASHER,LCK SPLIT
5/16 SS



FAS0552
WASHER,FLAT USS
5/16 SS




26650-0
FOAM TAPE
0.25X2.5X40.0



STEP 1

APPLY 26650-0 FOAM TAPE TO ANY SECTION ON FLOOR PLATES WITHOUT BOLTS TO MINIMIZE RATTLE TO FLOOR.




FAS0557

NO DRILL FLOOR PLATE

FAS0661

USE 26650-0 ROLL
CUT STRIPS OF 6" LENGTH**STEP 2**

FASTEN FLOOR PLATES TOGETHER WITH JOINER PLATE (IF APPLICABLE)

FAS0440
1/2 SOCKET
TIGHTEN AFTER PLATES ARE
MOUNTED TO VEHICLE IN STEP 3


FAS0557

JOINER PLATE

NO DRILL FLOOR PLATE

FAS0661

USE 26650-0 ROLL
CUT STRIPS OF 6" LENGTH


STEP 3***INSTALLATION TO VEHICLE B, C AND D-PILLARS***

USE FAS0408
1/2 SOCKET
IMPACT DRIVER



USING AN IMPACT DRIVER, TIGHTEN TRILOBULAR FAS0408 BOLT INTO D-RING LOCATIONS. THESE WILL SELF-THREAD INTO THE HOLES.

STEP 4***INSTALLATION TO VEHICLE D-PILLAR HIGH MOUNT***

USING AN IMPACT DRIVER, TIGHTEN FAS0413 BOLT INTO HIGH MOUNT GRAB HANDLE LOCATION.




FAS0334
FAS0678
FAS0413
USE T-55 TORX BIT
FLOOR PLATE BRACKET
FAS0440
FAS0557
NO DRILL FLOOR PLATE
FAS0661

FASTEN SHELVING UNIT TO FLOOR PLATE**FASTEN DRAWER UNIT TO FLOOR PLATE**

STEP 6


INSTALLING FRONT FLOOR PLATES UNDER PARTITION

A)



FLOOR PLATE

B)


DETAIL A
SCALE 1 : 2

PARTITION FOOTER

FLOOR PLATE


FAS0408
1/2 SOCKET
IMPACT DRIVER

C)



PARTITION

DETAIL B
SCALE 1 : 2FAS0018
7/16 SOCKET

STEP 7***INSTALLING FRONT UPPER OFFSET SHELF BRACKET IN 130" WB E-VAN
PASSENGER SIDE***

FRT. UPPER OFFSET BRKT. 66534

PASSENGER SIDE UPPER BRACKET NEEDS TO BE REPLACED DUE TO IT'S LOCATION TO THE END OF THE RAIL, CAP AND HARDWARE.
REPLACE STANDARD L BRACKET 45339 WITH THE OFFSET BRACKET 66534.
USE STANDARD FASTENERS THAT COME WITH THE RAIL KIT.