


PARGM2-NW, COMP PAR, SOLID, GM2



PRODUCT WEIGHT

60 LBS

WIDTH x DEPTH x HEIGHT

68" x 7" x 53.6"

CAPACITY

N/A

COLOR

BLACK

CATALOG NUMBER


PARGM2-NW

PRODUCT FEATURES

Compatible with 2015 model and newer

Composite partition with window for GM FSV provides a semi-sealed solution for separating the cab area from the cargo area. The composite partition features a full perimeter bulb seal that seals off the majority of the airflow from the cab area to the cargo area. This feature provides better climate control for the cab area and reduces noise transfer from the cargo area to the cab area. This version is a no drill footer solution that uses the front d-rings for floor mounting.

Driver Comfort Details




	DESCRIPTION	DIMENSION
SB	SEAT BACK ANGLE	25 degrees
MAXr	MAXIMUM DRIVER REACH	31"

SEE PAGE 2 FOR APPLICATION NOTES AND ACCESSORIES, OTHER PRODUCTS THAT WORK WITH THIS UNIT.


Accessory Chart

	Cargo Side			Cab Side		
	Base Partition BAGRKA1 REQUIRED (1 BAGRKA1 will allow for one accessory to be added)	PARHDW Fastener Kit Allow accessories to be added directly mounted to partition	PARGMCRG (mounting kit cargo side)	Base Partition 1/4" nuts and bolts REQUIRED	PARHDW Fastener Kit Allow accessories to be added directly mounted to partition	PARGMCAB (mounting kit cab side)
Available Accessories	-	-	-	-	-	-
PA7: Reflector kit	X	X	X	X	X	X
PA8: Fire ext.	X	X	X	X	X	X
PA9: First aid tray	X	X	X	X	X	X
PA10: Practice holder			X			X
PA11: Cab file			X	X		X
PA11NL: Catalog box			X	X		X
TA1: Four hook bar			X			X
CCD12: Center console 12"						X
TDC12: Tech desk 12"						X
PARGHGM: Handle kit			X			
TH30: 30lb tank holder			X			
TH50: 50lb tank holder			X			
UH50RM1: Rail mount kit			X			X
UH10: 1" hook			X			
UH25: 2.5" hook			X			
UH25CP-G: 2.5' hook comp			X			
UH50: 5" hook	X		X			

PARFTMCRG (shown in yellow)
Cargo side hardware mounting kit installed



PARFTMCAB (shown below in yellow)
Cab side hardware mounting kit installed



PARHDW Fastener Kit


Fastener kits allow for installation of smaller and lighter (up to 12 lbs.) Allows accessories to be directly mounted to the partition, such as: fire extinguisher, flare kit, first aid kits, acc.



ADRIAN STEEL®

Cargo Management Solutions for Commercial Vehicles

Assembly/Installation Instructions and Owners Manual



(PARGM2 SHOWN)

COMPOSITE PARTITIONS **PARGM2 & PARGM2-NW** FOR 2015 OR NEWER GM FSV VANS

- PRECAUTIONS -



 **CAUTION** 
**THE USE AIR IMPACT TOOLS CAN
OVER-TORQUE FASTENERS AND
CAUSE FASTENER FAILURE!**



 **CAUTION** 
**ALL INSTALLATION HOLES SHOULD BE SEALED
WITH SILICON OR BUTYL SEALANT TO PREVENT
EXHAUST FUMES FROM ENTERING THE VEHICLE!**



 **DANGER** 
**INSPECT FOR FUEL TANK, FUEL LINES, BRAKE LINES, HIGH
VOLTAGE BATTERIES AND ELECTRICAL LINES PRIOR TO
DRILLING TO AVOID DAMAGING CRITICAL VEHICLE SYSTEMS
OR INJURY TO INSTALLER DURING INSTALLATION PROCESS!**



 **CAUTION** 
**TO AVOID DAMAGING THE VEHICLE ALWAYS
USE DRILL STOPS WHEN DRILLING ANY IN-
STALLATION HOLES!**



- IMPORTANT WARRANTY REQUIREMENTS -

1. SUBSTITUTING ADRIAN STEEL SPECIFIED FASTENERS FOR ASSEMBLY AND/OR INSTALLATION WILL VOID YOUR PRODUCT WARRANTY.
2. ALL HOLES DRILLED INTO VEHICLE SHOULD HAVE THE RAW METAL EDGES SEALED WITH A SELF-ETCHING PRIMER TO RESIST CORROSION AND POTENTIAL FASTENER POINT FAILURE.
3. ALL FASTENERS USED IN THE INSTALLATION OF THIS PRODUCT SHOULD BE TIGHTENED TO THE TORQUE(S) SPECIFIED IN THESE INSTRUCTIONS.
4. THESE INSTRUCTIONS SHOULD BE KEPT WITH THE VEHICLE.

THE BASIC TOOLS NEEDED FOR MOST INSTALLATIONS



DRILL



DRILL BIT WITH
STOP



RATCHET, SOCKETS
AND/OR WRENCHES



SCREWDRIVERS





MEASURING TAPE

ADDITIONAL TOOLS MAY BE NEEDED FOR THIS INSTALLATION AND THEY WILL BE IDENTIFIED IN THE STEPS THAT FOLLOW.



WHEN INSTALLING PLUSNUTS MAKE SURE YOU USE THE CORRECT DRILL BIT WITH A STOP!

PLUSNUT SIZE	DRILL BIT SIZE
1/4-20 PLUSNUT, FAS0052	USE A 3/8" DIAMETER DRILL BIT WITH A STOP.
5/16-18 PLUSNUT, FAS0091	USE A 1/2" DIAMETER DRILL BIT WITH A STOP.
 OR  NOTE: A PLUSNUT SETTING TOOL IS REQUIRED FOR PLUSNUT INSTALLATION AND IS NOT SUPPLIED WITH THIS KIT. ORDER PLUSNUT TOOLS FROM ADRIAN STEEL (P.N. 22200-0) OR USE AN AIR POWERED PLUSNUT SETTING GUN.	
NOTE: If your vehicle contains carpet or a rubber floor mat you will need to prepare the mounting locations using a 1-3/16" carpet cutter.	1-3/16" DIAMETER CARPET CUTTER P.N. 31183-0. 




Step 01
Optional Based on Vehicle

If your vehicle contains carpet or a rubber floor mat you will need to prepare the mounting locations. (if not, skip to **STEP 02**)

Position the product to be installed into the vehicle and once you are satisfied with the mounting locations, mark the mounting locations. Using a 1-3/16" diameter carpet cutter. Select the appropriate floor spacers as shown in the illustration to the left. Set those aside for use later into the installation process.

Once you have prepared the carpet/floor mat for mounting, proceed to **STEP 02**.




Step 02
Prepare Mounting Locations

Using a drill and drill bit (see table at top of page for correct size) drill the mounting holes in the vehicle sheet metal to prepare for installing the plusnuts.

If you are thru-bolting at any of the locations simply drill a hole that is 1/16" larger than the bolt size(s) for those locations.

Once you have drilled the holes into the vehicle, the raw metal edges should be sealed using a self-etching primer to resist corrosion and potential fastener point failure.



Step 03
Setting Plusnuts



Use an Air Powered Plusnut Setting Gun to "set the plusnut" or if installing manually with hand tools, assembly the following.

- 1/4-20UNC Plusnut (FAS0052)
- FAS0080 SCREW, HXHD, 1/4-20UNCx2.00, G8
- FAS0067 WASHER, FLAT, 1/4"ID
- 22200-0 PLUSNUT TOOL
- 5/16-18UNC Plusnut (FAS0091)
- FAS0095 SCREW, HXHD, 5/16-18UNCx2.00", G8
- FAS0086 WASHER, FLAT, 5/16"ID
- 22200-0 PLUSNUT TOOL


Place barrel of the plusnut body in sheet metal thru hole until flange is flush with sheet metal.

Using a 9/16" combination wrench of plusnut tool body and a second hand wrench, ratchet, or air tool, rotate the hex bolt head CW to draw plus nut flanges up (set the plusnut).

Remove hex bolt, washer, and plusnut. Inspect installation.

PARTS YOU WILL USE FOR STEP 04	FAS0752 SPRING CLIP (5) EACH	FAS0711 SPRING CLIP (2) EACH	59083 FLOOR SPACER (2) EACH	DRILL/DRIVER WITH TORX SOCKET
				




Instructions for Step 04



ATTACH THE TWO SMALL SPRING CLIPS TO THE FOOTER RAIL WITH THE THREADED PORTION FACING OPPOSITE OF THE FLANGE.


ATTACH THE FIVE LARGE SPRING CLIPS TO THE FOOTER RAIL WITH THE THREADED PORTION FACING THE SAME SIDE AS THE FLANGE.

REMOVE BOTH OF THE FRONT D-RINGS ON EACH SIDE BEHIND THE SEATS. PLACE ONE FLOOR SPACER OVER EACH LOCATION AND FASTEN THE FOOTER RAIL TO THE VEHICLE USING THE OEM BOLT FROM THE D-RINGS.


PARTS YOU WILL USE FOR STEP 05	50776-B, B-PILLAR CLAMP BRKT (2) EACH	51243-B, JOINING BRKT ASSM, PARGM (2) EACH	FAS0708, 5/16x1.25 BHCS (4) EACH	FAS0676 5/16 LT NYLOCK NUT (4) EACH
				
	3/16" ALLEN WRENCH	DRILL/DRIVER	1/2" DEEP WELL SOCKET	FAS0085 5/16 LOCK WASHER (4) EACH
				

Instructions for Step 05

ASSEMBLE B-PILLAR BRACKETS AS SHOWN.







STREETSIDE BRACKET ASSEMBLY



CURBSIDE


ATTACH THE JOINING BRACKETS TO THE B-PILLAR CLAMP BRACKETS AS SHOWN TO CREATE A CURBSIDE AND STREETSIDE ASSEMBLY OF EACH AS SHOWN USING THE ABOVE LISTED FASTENERS.





PARTS YOU WILL USE FOR STEP 06	SS MTG BRKT ASSEMBLY FROM PREVIOUS STEP 	CS MTG BRKT ASSEMBLY FROM PREVIOUS STEP 	DRILL/DRIVER 	9/16" DEEPWELL SOCKET 

Instructions for Step 06

PULL BACK DOOR SEALS AS SHOWN.



CAREFULLY PULL DOOR SEALS AWAY FROM THE B-PILLAR FLANGES NEAR THE MIDDLE OF THE OPENING(S) AS SHOWN TO EXPOSE B-PILLAR SHEET METAL FLANGES ON BOTH SIDES OF THE CURBSIDE B-PILLAR AND ON THE FRONT SIDE OF THE STREETSIDE B-PILLAR.

<p>PARTS YOU WILL USE FOR</p> <p>STEP 07</p>	<p>SS MTG BRKT ASSEMBLY FROM PREVIOUS STEP</p> 	<p>CS MTG BRKT ASSEMBLY FROM PREVIOUS STEP</p> 	<p>DRILL/DRIVER</p> 	<p>9/16" DEEPWELL SOCKET</p> 

Instructions for Step 07

ATTACH B-PILLAR BRACKETS AS SHOWN.


STREETSIDE BRACKET



CURBSIDE BRACKET



POSITION THE B-PILLAR BRACKETS SO THAT THE BRACKET PORTION WITH THE 5/16" STUDS IS TOWARDS THE TOP OF THE BRACKET AND THE STUDS ARE FACING REARWARD IN THE VEHICLE. THE HEMMED FLANGE OF THE BRACKETS SHOULD BE ATTACHED OVER THE B-PILLAR FLANGE SHEET METAL FLANGES. POSITION THE BRACKETS WITH THE TOP EDGE EVEN WITH THE PLASTIC B-PILLAR TRIM EDGE WHERE THE SEAT BELT EXITS THE TRIM. ONCE THE BRACKET(S) ARE IN POSITION, TIGHTEN THE NUTS ON THE CARRIAGE BOLT(S) TO TIGHTEN THE CLAMP BRACKETS TO THE B-PILLARS.



PARTS YOU WILL USE FOR STEP 08	OEM DOOR SEALS			


Instructions for Step 08

RE-ATTACH DOOR SEALS.




RE-ATTACH DOOR SEALS ONTO THE B-PILLAR FLANGES AND OVER THE B-PILLAR BRACKET HEMMED EDGES.

MAKE SURE THAT THE INSIDE EDGE OF THE DOOR SEALS ARE PROPERLY SEATED OVER THE B-PILLAR BRACKETS AND THAT THE SEAL EDGES ARE NOT CURLED UNDER.


PARTS YOU WILL USE FOR STEP 09	50777-B CROSS CHANNEL (1) EACH 	FAS0245 5/16" FLAT WASHER (4) EACH 	FAS0248 5/16" LOCKNUT (4) EACH 	DRILL/DRIVER 
	1/2" SOCKET 			

Instructions for Step 09

ATTACH CROSS CHANNEL AS SHOWN.



STREETSIDE ATTACHMENT



CURBSIDE ATTACHMENT


NOTE: IF INSTALLING OPTIONAL PARGHGM GRAB HANDLE, REFER TO INSTALL INSTRUCTIONS 52609 BEFORE CONTINUING!

IN ORDER TO ENGAGE THE STUDS TO THE SLOTS IN THE CHANNEL, APPLY REARWARD PRESSURE TO THE CURBSIDE MOUNTING BRACKET TO ALLOW THE STUDS TO ENGAGE THE TWO SLOTS.

ATTACH CROSS CHANNEL ASSEMBLY TO B-PILLAR MOUNTING BRACKETS. POSITION CROSS CHANNEL WITH RIV-NUTS IN THE CHANNEL FACING TOWARDS THE REAR OF THE VEHICLE AS SHOWN. START ON THE STREETSIDE AND POSITION THE MOUNTING HOLES TO BE OVER THE BRACKET STUDS AS SHOWN AND THEN POSITION THE OPPOSITE END OVER THE CURBSIDE BRACKET STUDS.


PLACE FLAT WASHERS AND THE NYLOCK NUTS ON THE STREETSIDE AND TIGHTEN.

PLACE FLAT WASHERS AND THE NYLOCK NUTS ON THE CURBSIDE AND TIGHTEN.

PARTS YOU WILL USE FOR STEP 10	51249-B ACC. MTG. CHANNEL (2) EACH	FAS0018 1/4X5/8 HH SFLG SCRW (4) EACH	DRILL/DRIVER	7/16" SOCKET
				
	FAS0711, SPRING CLIPS (2) EACH			
				

Instructions for Step 10

ATTACH TWO SPRING CLIPS TO THE CROSS CHANNEL IN THE 5TH AND 10TH SLOTS FROM THE CURBSIDE END AS SHOWN. FASTEN ACCESSORY MOUNTING CHANNELS TO THE FOOTER AND CROSS CHANNEL AS SHOWN.



ATTACH TWO SPRING CLIPS TO THE CROSS CHANNEL IN THE 5TH AND 10TH SLOTS WITH THREADED PORTION FACING TOWARDS THE REAR OF THE VEHICLE AS SHOWN.

ATTACH TWO ACCESSORY MOUNTING CHANNELS TO THE FOOTER AND CROSS CHANNEL AS SHOWN.

POSITION THE MOUNTING CHANNELS OVER THE FRONT FACE (CAB SIDE) OF THE FOOTER AND CROSS CHANNEL WITH THE MOUNTING CHANNELS J-LEGS FACING REARWARD.


ATTACH THE CHANNELS USING 1/4 FLANGE SCREWS AND FASTEN INTO THE SPRING CLIPS AS SHOWN AND TIGHTEN.

<p>PARTS YOU WILL USE FOR</p> <p>STEP 11</p>	<p>CCD6/CCD12</p>			
	<p>THIS PRODUCT AND ASSOCIATED PARTS ARE NOT INCLUDED IN THIS KIT!</p>			

Instructions for Step 11 Supplemental

ATTACH STREETSIDE MOUNTING BRACKET AS SHOWN.

STEP 11a



STEP 11b



STEP 11c



NOTE:
SKIP THIS STEP IF YOU ARE NOT INSTALLING A CCD6 or CCD12 CENTER CONSOLE!

STEP 11a


FOLLOW THE INSTRUCTIONS FOR THE CCD6/CCD12 INSTALLATION UP TO THE INSTALLATION OF THE 06665-1 BRACKETS.

STEP 11b

USING THE FASTENERS AND 06665-1 BRACKET FROM THE CCD6 HARDWARE KIT FOLLOW THE INSTRUCTIONS FOR MOUNTING THE BRACKET TO THE CCD6/CCD12 ON THE STREETSIDE OF THE CENTER CONSOLE.


STEP 11c

PUSH BRACKET TO BE TIGHT AGAINST THE ACCESSORY MOUNTING CHANNEL AND FASTEN USING FAS0062, FAS0067 AND FAS0055 FROM THE CCD6 KIT, FULLY TIGHTEN ALL OF THE FASTENERS.

PARTS YOU WILL USE FOR STEP 12	51239 PARTITION PANEL ASSM.,	51252 PARTITION PANEL ASSM. W/WINDOW,	51255 BULB SEAL, PARGM (2) EACH	
		OR 		
	SMALL RUBBER MAL- LET			
				

Instructions for Step 12

ATTACH BULB SEALS TO PARTITION AS SHOWN.



BULB FACING THIS DIRECTION TOWARDS B-PILLAR TRIM.

STREETSIDE CORNER

CURBSIDE CORNER

ATTACH 51255 SEALS TO BOTH SIDES OF THE PARTITION PANEL STARTING AT THE BOTTOM CORNER AND WORKING UP OVER TO THE TURN AREA AT EACH UPPER CORNER.

PARTS YOU WILL USE FOR STEP 13				

Instructions for Step 13

WHEN INSTALLING A LINER KIT WITH THIS PARTITION, PREP STREETSIDE HEADER AREA OF VEHICLE.

IF YOU ARE NOT INSTALLING A LINER KIT WITH THIS PARTITION SKIP THIS STEP!

REMOVE AND DISCARD THE STREETSIDE HEADER TRIM THAT IS LOCATED DIRECTLY BEHIND THE HEADLINER AREA.



(SHOWN WITH TRIM PIECE REMOVED)



IF YOU ARE NOT INSTALLING A LINER KIT SKIP THIS STEP!


REMOVE THE PLASTIC TRIM PIECE THAT IS LOCATED ON THE STREETSIDE HEADER JUST BEHIND THE HEADLINER.

DISCARD THIS PART.

PARTS YOU WILL USE FOR STEP 14	51247-B HEADER ASSM, GM (1) EACH	FAS0271, 5/16 THREAD FORM SCREW (2) EACH	DRILL/DRIVER	7/16" SOCKET
				

Instructions for Step 14

INSTALL HEADER BRACKET INTO VEHICLE.




INSTALL HEADER BRACKET TO VEHICLE ROOF BOW THAT IS IN LINE WITH THE B-PILLAR AREA. THE ROOF BOW MOUNTING SURFACE IS 2-1/2" FORWARD OF THE BACK EDGE OF HEADLINER.

POSITION BRACKET FLANGE WITH PLUSNUTS FACING TOWARD THE REAR OF THE VEHICLE AND THE FLANGE POINTING DOWNWARDS CENTER THE BRACKET AGAINST THE ROOFBOW AND SECURE USING THE TWO THREAD FORMING SCREWS INTO THE 1/4" HEX HOLES IN THE ROOFBOW. TIGHTEN BOTH SCREWS TO SECURE.

PARTS YOU WILL USE FOR STEP 15	51248-B MTG. PLATE, PARGM (2) EACH			
				


Instructions for Step 15

INSTALL MOUNTING PLATES.



INSTALL A MOUNTING PLATE ON BOTH B-PILLAR BRACKETS.


PLACE MOUNTING PLATE OVER THE TWO FASTENER STUDS ON BOTH OF THE B-PILLAR BRACKETS ON THE REARWARD SIDE OF THE BRACKET AS SHOWN.

PARTS YOU WILL USE FOR STEP 16	PARTITION PANEL ASSEMBLIES WITH BULB SEALS INSTALLED		
		OR	


Instructions for Step 16

INSERT PARTITION PANEL INTO VEHICLE.

INSERT TOP FIRST THEN PIVOT FORWARD AND INTO PLACE AGAINST FOOTER.




INSERT PARTITION INTO VEHICLE WITH BOTTOM EDGE WAY FROM THE FOOTER WITH THE TOP CONTACTING THE HEADER AREA FIRST AND THEN PIVOT UP AND FORWARD INTO PLACE AGAINST B-PILLARS AND FOOTER.

PARTS YOU WILL USE FOR STEP 17	50941-B RAIL AD, PARFTL	36496-0 END CAP (2) EACH	FAS0708 BHCS 5/16X1-1/4 (5) EACH	FAS0085 5/16 LOCK WASHER (5) EACH
				
	DRILL/DRIVER	3/16" HEX DRIVER BIT	SMALL RUBBER Mallet	
				

Instructions for Step 17

ATTACH AD RAIL TO PARTITION AS SHOWN.




INSERT A PLASTIC END CAP INTO EACH END OF THE AD RAIL AS SHOWN

ATTACH THE AD RAIL AND PARTITION PANEL TO THE CROSS CHANNEL USING THE ABOVE LISTED 5/16" FASTENERS AT FIVE (5) PLACES AS SHOWN.

NOTE: DO NOT FULLY TIGHTEN THESE FIVE (5) FASTENERS AT THIS STEP!

ADJUSTMENTS MAY BE NEEDED DURING THE NEXT STEP!



PARTS YOU WILL USE FOR STEP 18	51248-B MTG. PLATE, PARGM (2) EACH	FAS0676 5/16 LT NYLOCK NUT (4) EACH	DRILL/DRIVER	1/2" SOCKET
				

Instructions for Step 18


ATTACH MOUNTING PLATES AS SHOWN.



INSTALL A MOUNTING PLATE ON BOTH B-PILLAR BRACKETS.

PLACE MOUNTING PLATE OVER THE TWO FASTENER STUDS ON BOTH OF THE B-PILLAR BRACKETS AND AGAINST THE PARTITION PANEL SURFACE.

INSTALL TWO (2) 5/16" NY-LOCK NUTS ON BOTH CURSIDE AND STREETSIDE AND FULLY TIGHTEN.


PARTS YOU WILL USE FOR STEP 19	FAS0668 BHCS 5/16-18X0.75 (5) EACH	FAS0085 5/16 LOCK WASHER (5) EACH	FAS0833 WASHER, CUP (5) EACH	FAS0253 WASHER, IV-2 (5) EACH
				
	DRILL/DRIVER	3/16" HEX DRIVER BIT		
				

Instructions for Step 19

ATTACH PARTITION PANEL AS SHOWN.




ATTACH THE PARTITION PANEL TO THE PARTITION FOOTER USING THE ABOVE LISTED 5/16" FASTENERS AT FIVE (5) PLACES AS SHOWN. FULLY TIGHTEN THESE FIVE (5) FASTENERS.




PARTS YOU WILL USE FOR STEP 20	DRILL/DRIVER	3/16" HEX DRIVER BIT		
				

Instructions for Step 20

TIGHTEN AD RAIL FASTENERS.




FULLY TIGHTEN THE FIVE (5) FASTENERS THAT ATTACH THE AD RAIL.


PARTS YOU WILL USE FOR STEP 21	FAS0708 BHCS 5/16X1-1/4 (2) EACH	FAS0085 5/16 LOCK WASHER (2) EACH	FAS0833 WASHER, CUP (2) EACH	FAS0253 WASHER, IV-2 (2) EACH
				
	DRILL/DRIVER	3/16" HEX DRIVER BIT		
				

Instructions for Step 21

SECURE PANEL TO HEADER BRACKET.



ATTACH THE PARTITION PANEL TO THE HEADER BRACKET USING THE ABOVE LISTED FASTENERS AND FULLY TIGHTEN.




PARTS YOU WILL USE FOR	PARHDW OPTIONAL KIT	DRILL/DRIVER	7/16" SOCKET	
<p>STEP 22</p>				

Instructions for Step 22 Supplemental

NOTE:
IT IS ACCEPTABLE TO INSTALL ACCESSORIES THAT WEIGH LESS THAN 15 POUNDS DIRECTLY TO THE CARGO-SIDE OF THE PARTITION PANEL.

YOU MUST ORDER HARDWARE KIT(S) PARHDW FOR THE CORRECT FASTENERS

FIRE EXTINGUISHER SHOWN FOR EXAMPLE.



DETERMINE MOUNTING POSITION FOR ACCESSORY AND MARK HOLE LOCATION(S). DRILL 5/16" DIAMETER HOLES THRU PARTITION PANEL. USE 1/4" TRUSS HEAD SCREWS THRU THE ACCESSORY WITH CUP WASHERS FROM THE CAB SIDE OF THE PARTITION AND USE NYLOCK FLANGE NUTS TO SECURE ACCESSORY.

NOTE:
FOR MOUNTING ACCESSORIES TO THE CAB SIDE OF THE PARTITION PANEL THE MOUNTING RAILS INCLUDED WITH THE PARTITION SHOULD BE USED. ADDITIONAL RAILS CAN BE ORDERED WITH **PARG-MCAB** MOUNTING KIT.

FOR MOUNTING HEAVIER AND/OR BULKY ACCESSORIES TO THE CARGO SIDE OF THE PARTITION THE ACCESSORY MOUNTING KIT **PARGMCRG** SHOULD BE ORDERED AND INSTALLED.

YOUR INSTALLATION IS NOW COMPLETED.