


| INSTR. NUMBER                        | PG:      | REV:     | ITEM NO. | PART NUMBER | DESCRIPTION                    | QTY. |
|--------------------------------------|----------|----------|----------|-------------|--------------------------------|------|
| : <b>INS-PEPK</b>                    | <b>1</b> | <b>B</b> | 1        | PEP1030-G   | END PANEL,10X30, GRAY          | 2    |
|                                      |          |          | 2        | PEPFMB10-G  | END PANEL,T,FLR MNT,10, GRAY   | 2    |
| PART NUMBER : <b>PEPKT1030G</b>      |          |          | 3        | PEPTB-G     | END PANEL TRUCK BRACE, G       | 2    |
|                                      |          |          | 4        | BAGPEPKT    | BAG FOR TRUCK END PANEL KITS   | 1    |
| PART DESC. : END PANEL KIT,T,10X30,G |          |          | 5        | INS-PEPKT   | INSTALL INSTRUCTIONS FOR PEPKT | 1    |



**TOOLS NEEDED:**

- 1/2" Socket
- 8mm ALLEN BIT
- DRILL
- 7/16" DRILL BIT
- MARKER

**GET TO KNOW THE VEHICLE** - AT THE BEGINNING OF ANY INSTALLATION, CHECK THE LOCATION OF THE FUEL TANK, FUEL LINES, BRAKE LINES, HIGH VOLTAGE BATTERIES AND WIRING HARNESES TO AVOID INJURY OR PROPERTY DAMAGE FROM TOOL CONTACT.

**SEAL ALL EXTERIOR HOLES** - ALL INSTALLATION HOLES SHOULD BE SEALED WITH BUTYL TAPE OR SILICON TO PREVENT WATER AND EXHAUST GASES FROM ENTERING THE VEHICLE.

**CONTROL DRILL DEPTH** - TO AVOID DAMAGE TO THE VEHICLE, USE A DRILL STOP OR CLEARED STEP BIT WHEN DRILLING INSTALLATION HOLES.

**ALWAYS ADD PRIMER** - WHEN ADDING INSTALLATION HOLES BE SURE TO USE A SELF-ETCHING PRIMER TO PREVENT CORROSION, FASTENER FAILURE AND INJURY.

**MOUNTING POINTS MUST HAVE METAL-TO-METAL CONTACT** - USE PROVIDED MOUNTING SPACERS TO ACCOMMODATE FOR VEHICLE FEATURES, CARPET OR SUBFLOORS.

**PROVIDE CLEARANCE FOR SPACERS** - IF THE INSTALLATION VEHICLE CONTAINS A CARPET OR SUBFLOOR, USE A 1-3/16" DIAMETER CARPET CUTTER (P/N: 31183-0) AT ALL MOUNTING LOCATIONS TO OPEN UP ROOM FOR SPACERS.


**CHECK SPACER ORIENTATION** - BE SURE THAT THE INDENT IN THE SPACER COVERS THE PLUSNUT HEAD; THIS ENSURES THE MOST METAL-TO-METAL CONTACT AND REDUCES VIBRATION.

**PLUSNUT INSTALLATION** - A PLUSNUT GUN IS RECOMMENDED FOR PLUSNUT INSTALLATION FOR ITS PRODUCTION SPEED. HOWEVER, A PLUSNUT SETTING TOOL CAN ALSO BE USED (P/N: 22200-0).


**THRU-BOLT CLEARANCE** - WHEN USING A THRU-BOLT AT ANY MOUNTING LOCATION, BE SURE THAT YOUR HOLE HAS 1/16" CLEARANCE.

**FASTENERS USED**



**BAG REFERENCE: BAGPEPKT**




FAS-SQR  
CAGE NUT, 5/16-18  
QTY: 12




FAS0438  
SCREW, HFLNG 5/16-18X.75  
QTY: 12




FAS0081  
SCREW, HH 5/16-18X.75.  
QTY: 10



FAS0921  
5/16-18 THREADED INSERT.  
QTY: 10



FAS0086  
WASHER, FLAT USS 5/16  
QTY: 10



FAS0098  
WASHER, LCK SPLIT 5/16  
QTY: 10

**INTENTIONALLY LEFT BLANK**

**STEP 1 - MOUNT FLOOR MOUNTS TO END PANELS**

**Step 1.1**

**INSTALL  
FAS0915 ON  
THE OUTER  
FACE OF THE  
END PANEL**

**Step 1.3**


**FULLY TIGHTEN**

**FAS0438  
(4 PLACES)  
1/2" SOCKET**


**STEP 1.1  
BOTH END PANELS**

**(4) PLACES TOTAL**

**THESE WILL BE USED  
TO MOUNT BRACES**



**STEP 1.2**



**SNAP FAS0915  
INTO END PANEL  
(8 PLACES)**



**REFERENCE: GO TO INS-PECK FOR END CAP AND SHELF MOUNTING INSTRUCTIONS**



**STEP 2 - MOUNT ASSEMBLED SHELVING UNIT TO EXTENDOBED**

**Step 2.1**

**MARK AND DRILL HOLES USING A 7/16" DRILL BIT (10 PLACES)**

**Step 2.2**

**FULLY TIGHTEN FAS0086, FAS0098, FAS0081, AND FAS0921 (10 PLACES PER UNIT) 1/2" SOCKET**



**STEP 2.2**

